ITSU

Electric Toothbrush

User Manual

IS0213 使用說明書

Instruction Manual (EN)

Important safety tips

1. Users new to electric toothbrushes may experience slight numbing or other sensations after the first few uses. Please do not worry, this discomfort should disappear after a couple of days. And if you still have some discomfort after then, please consult your dentist.
2. Do not disassemble, repair or alter the product without authorization.
3. Do not knock or drop the product if productis defective, please stop using it.
4. Please check if the local voltage is suitable with the marked voltage before being charged.
5. If you've had oral or gum surgery in the past two months, please consult your dentist before using the product.
6. If you experience bleeding after repeated use or the bleeding continues for more than 7 days, please consult your dentist.
7. This product is designed for teeth, gums and tongue cleaning, not for other purpose.
8. This product is not a toy. Children should be supervised to ensure proper usage.
9. Avoid placing in high temperature conditions or in direct sunlight.
10. Please keep the charging port dry while charging and use the original charging cable!

Component Name



Changing the toothbrush head



Slide toothbrush head down as direction A, tum clockwise let A meet B



Turn toothbrush head counter clockwise until A meet B,then pull out as direction①

Features

1. Clean oral effectively with 40000 times per minute.

2. With 5 modes (White、Clean、Sensitive、Polish Massage) to meet different demands.

3. Advantages: ergonomic design, waterproof, anti-skid and comfortble to hold.

4. The product runs for up to 120 days on a full charge with safe and durable lithium battery, and the charging indicator light will flash to alert the product needs to be charged.

5. Smart mode memory, 2 minutes auto stop and 30 seconds timer reminder for moving help you get into good brushing habits.

6. Battery indication:
When the product stop working, the LED indicators will light up.
Battery level: <20%, the bottom LED indicator lights up.
Battery level: 20%-40%, the bottom two LED indicators light up.
Battery level: 40%-60%, the bottom three LED indicators light up.
Battery level: 60%-80%, the bottom four LED indicators light up.
Battery level: 80%-100%, all five LED indicators light up.

Using the toothbrush

1. Attach the brush head and make sure it is locked inplace. Wet the bristles and apply appropriate amount of toothpaste.

2. Place toothbrush in mouth before turning on.

3. Gently move the brush head across each sectionof the teeth for 10 seconds, including front、 back and chewing surfaces.

4. The multifunction button needs continued operationin 5 seconds for first mode switching, otherwise, it will stop working automatically.

5. Press the multifunction button you would have a choice of 5 modes.

6. The toothbrush will automatic turn off after 2 minutes of cleaning.

Charging instructions

1. When battery capacity is low,the product will fail to start or the charging indicator light will flash for 10 times to alert the product needs to be charged.

2. Suitable for charger with USB charging cable which is included in the package.

3. The indicator lights will be on from the bottom one when charging,and will turn off automatically when the battery is fully charged.

4. For the first time use or the battery was undercharged for long period of time, the indicator may not light in the first 5 minutes as the product had run out of power.

Removing the rechargeable battery

This product contains lithium battery. Before being discarded, please take out the battery and recycle or dispose according to the local waste disposal management regulations. If in doubt, consult your local waste management department.

When removing the battery, you need the following tools: pliers, scissors.

Notices:
when you decide to discard the toothbrush, you need to take out the battery. Make sure the battery is discharged before removing.

When using the tools, please observe the basic safety rules and take protective measures to avoid injury.



① First remove the brush head and use a saw to mark 10mm from the saw the position.



② After sawing



③ Put the swing bar against the table top, hold the handle and press down, you can remove the inside bracket.



④ After removing the bracket, you can see the battery. Take it out of the battery slot and cut the battery wire or pad.

Product information

Model: IS0213

Input Power: 1.5W

Charging time: ≤4hours

Bristle Diameter: 0.152mm

Working temperature: 5-40℃

Input Voltage: 5V ⎓

Operative standard:

GB39669-2020

Trouble shooting

Case	Possible cause	Solution
Vibration strength become weaken	Excessive force	Gently put the brush head on your teeth
The work time is short	1. The handle is not in the right place which causing the charging failure 2.The battery power is low.	1. Ensure to put it in a right way when charging 2.To extend the charging time
The product doesn't work	1.The battery power is low. 2.Other causes.	1.Please charge the battery 2.Please contact the Seago customer service to deal with it.

Warranty Claim

1. Warranty is not transferable.
2. This warranty is effective only if the product is purchased from ITSU.
3. Proof of purchase (original receipt) is required for all warranty repairs.
4. All implied warranties, including but not limited to these implied warranties of fitness and merchantability, are limited to the duration stated in the warranty policy.
5. Damage due to misuse, improper treatment and unauthorized modification and repair are not covered by this warranty.
6. Warranty does not cover accessories and attachments which do not belong to the massage unit.
7. Warranty is not effective to rental, business, commercial, institutional or other non-residential users.
8. All services covered by this warranty must be approved by ITSU and repaired By authorized technicians only.
9. If replacement parts for defective materials are not available, ITSU reserves the right to make substitution in lieu of repair or replacement.

Contact Us

ITSU WORLD SDN. BHD. (reg. no. 1137036-K)
Unit BO03-B-13A-1,
Menara 3A, KL Eco City,
No.3, Jalan Bangsar,
59200 Kuala Lumpur.
Tel: 1700-81-4878

ITSU World（HK) Limited
Flat A6，20th Floor，TML Tower，
No.3 Hoi Shing Road，
Tsuen Wan，
N.T.
Tel：+852 3611 2228

PT Healthy World
Lodan Center Block O No 20
Jalan Lodan Raya No 2
Jakarta Utara 14430
Tel: +62 21-6983 1123

使用說明

重要安全提示

1. 首次使用電動牙刷時，有部分人群會有些不適應的情況(例如有刺激和發麻的感覺)， 請不要擔心這種現象，一般會在兩天后逐漸減弱，如仍舊感覺不適，請停止使用本產品並諮詢您的牙醫。

2. 請勿私自對產品進行拆卸、修理、改造等。

3. 請勿敲打或跌落本產品，如果產品有任何損壞，請勿使用。

4. 在您連接電源之前，請檢查本地的電源電壓是否與產品所標示的電壓相符。

5. 如果您的口腔或牙跟在過去2個月內曾動過手術或在使用本牙刷後出血狀況或出血狀況延續超過一星期，請向您的牙醫諮詢後再使用。

6. 若您身上裝有心律調整器或曾裝入其他裝置, 請於使用前諮詢您的醫師或植入裝置的製造商。

7. 本產品只適用於清潔牙齒、牙齦、舌頭,請勿用作其他用途。

8. 請放置在嬰兒和兒童接觸不到的地方，不可當玩具使用。

9. 本產品僅供室內使用，請勿將產品放在高溫、陽光直射的地方。

10. 充電時必須保證充電口乾燥! 請使用原裝充電線!

部件名稱



刷頭更換安裝方法

安裝



將新的牙刷頭按A的方向套下，使A與B對齊，再向箭頭方向擰緊A與T對齊。

取下



將牙刷頭按箭頭方向擰至A與B對齊，再向①的方向取下。

功能特點

1. 每分鐘高達40000次的微刷動，清潔口腔。
2. 產品具有亮白、清潔、輕柔、拋光、按摩5種模式，滿足不同需求。
3. 機身符合人體工程學設計，易於手持，具有防水防滑功能。
4. 牙刷採用安全耐用的鋰電池,續航時間可達120天，並帶有缺電提醒功能。
5.牙刷自帶30秒換區提醒、2分鐘智能定時及模式記憶功能,科學刷牙有益口腔健康。
6.電量指示
聲波電動牙刷關機後，五顆指示燈可顯示大約剩餘電量。
一顆指示燈亮：電量小於20%　　二顆指示燈亮：20%~40%
三顆指示燈亮：40%~60%　　四顆指示燈亮：60%~80%
五顆指示燈亮：80%~ 100%

電動牙刷使用方法

1. 安裝刷頭，將它完全固定在手柄上，沾濕刷毛並擠上適量牙膏。
2. 啟動產品前將塗有牙膏的電動牙刷放進嘴裡。
3. 按動開關，以輕微上下擺動的方式由外及內橫向移動牙刷對牙齒的前、後和咀嚼三面各花10秒時間。
4. 開啟產品後，5秒內按開關鍵可切換檔位，5秒內無操作再次按開關鍵將關閉產品
5. 按下功能按鍵，可根據不同情況切換至合適模式。
6. 當一個區域刷牙時間達到30秒時，電動牙刷會停頓提醒你移向下一個區域繼續清洗，2分鐘後自動關閉。

充電說明

1.當使用結束後發現5個白色指示燈閃爍或者產品不能被正常開啟，此時說明電池電量不足，需要對產品進行充電。
2.用包裝內原裝的充電線連接牙刷和USB充電器或含有USB接口的設備(如電腦)。
3.充電時五個檔位指示燈從下往上累加亮起，充滿電後指示燈熄滅。
4.首次使用或者長時間未使用可能出現充電前5分鐘指示燈不亮，這是電池電量不足引起，屬正常現象。

取出充電電池

本產品使用的是鋰電池，產品壽命終結，丟棄產品前，請務必取出電池,並按當地的廢棄物管理條例進行回收或處置。若有疑問，請諮詢當地廢棄物管理部門。拆卸電池您需要以下工具：鋸子剪鉗。

注意:
僅丟棄產品時拆卸電池。拆卸前請確保電池電量已耗盡。使用工具請遵守基本安全規則並做相應的保護措施,避免受傷。



① 先拆下刷頭，並使用鋸子從標註10mm處位置鋸開。



② 鋸開後效果



③ 將擺桿頂住桌面，握住手柄往下壓即可拆卸出內部支架。



④ 支架拆出後即可看見電池，將電池從電池槽內取出並剪斷電池導線或焊盤。

產品信息

型號： IS0213
額定輸入功率： 1.5W
充電時間： ≤4小時
刷絲直徑： 0.152mm 軟毛
工作環境： 5-40℃
額定輸入電壓： 5V ⎓
執行標準： GB39669 -2020
GB / T40362-2021 合格

故障診斷

情況	可能原因	解決措施
震動強度減弱	牙刷強壓在牙齒上	將刷頭輕輕的放在牙齒上
牙刷工作時間短	1. 手柄沒有放好，導致充電失敗 2. 電量不足	1. 電量不足 2. 其他原因
牙刷不工作	1. 保證充電時擺放方式正確 2. 延長充電時間	1. 請進行充電 2. 聯繫客服處理

保修權限

1. 本保修權限不可轉讓。
2. 本保修服務僅對在 ITSU 購買的產品有效。
3. 當要求保修服務時，請出示購買證明（正本收據）。
4. 所有報修項目，包括但不限於這些健身及適銷性的保修項目有效期限需視保修政策而定。
5. 因錯誤使用、處理不當以及未經授權私自改裝和維修產品而導致的損壞，不屬於保修範圍。
6. 此保修範圍不包括不屬於產品本身的附件。
7. 此保修範圍不適用於租賃、交易、商業、機構、或其他非住宅用戶。
8. 此保修範圍內所涉及的維修服務需經過 ITSU 授權，且必須由授權的技術人員維修。
9. 若需更換的維修附件缺貨，ITSU 有權採用替代配件進行維修。

联络我们

ITSU WORLD SDN. BHD. (reg. no. 1137036-K)
Unit BO03-B-13A-1,
Menara 3A, KL Eco City,
No.3, Jalan Bangsar,
59200 Kuala Lumpur.
Tel: 1700-81-4878

ITSU World（HK) Limited
Flat A6，20th Floor，TML Tower，
No.3 Hoi Shing Road，
Tsuen Wan，
N.T.
Tel：+852 3611 2228

PT Healthy World
Lodan Center Block O No 20
Jalan Lodan Raya No 2
Jakarta Utara 14430
Tel: +62 21-6983 1123